

# Instructions to RESTORE POWER



Reconnect Collar  
Installed

Reconnect Collar

Note: Orange arrows are pointing to location of the Activation Switch (see detail below)

Activation Switch  
Located on the bottom  
of the Reconnect Collar

## Follow these STEPS

- 1 The Red "Indicator" light and Green "On" activation switch are located on the bottom of the reconnect collar.
- 2 When the reconnect collar is activated from our office, the Red "Indicator" light will be blinking.
- 3 When the Red "Indicator" light is blinking, reach underneath the reconnect collar and press the Green "On" activation button
- 4 Power should be restored and meter should be turning.
- 5 In the event power is not restored please call Snapping Shoals EMC at 770-786-3484.

